



FlowCon E-JUST.1 DN15-25 (1/2"-1") • Dynamic Balancing Valve

Valve housings		Insert	Accessories	
① A15.I	Valve housing, DN15 (1/2")	④ E-JUST.1.x.x 20 mm E-JUST insert	⑤ ACC0080	Flushing cap
① A20.I	Valve housing, DN20 (3/4")		⑥ 2 x ACC00113	P/t plug with gasket
① A25.I	Valve housing, DN25 (1")		⑦ 2 x ACC1B03000	Plug with gasket
② AB15.I	Valve housing, DN15 (1/2")		⑧ 2 x 1C000xx	Union end connection
② AB20.I	Valve housing, DN20 (3/4")		⑨ ACC0001	Adjustment key
② AB25.I.K	Valve housing, DN25 (1")		IA	Insulation shell for ① (not shown)
③ ABV.1	Valve housing, DN15/20/25 (1/2", 3/4", 1")		IAB	Insulation shell for ② (not shown)



FlowCon E-JUST.2 DN25-40 (1"-1 1/2") • Dynamic Balancing Valve

Valve housings		Insert	Accessories	
①	AB25.I	Valve housing, DN25 (1")	③	E-JUST.2.Y.G 40 mm E-JUST insert
①	AB32.I	Valve housing, DN32 (1 1/4")	④	ACC0081 Flushing cap
②	ABV.2	Valve housing, DN25/32/40 (1", 1 1/4", 1 1/2")	⑤	2 x ACC00113 P/t plug with gasket
			⑥	2 x ACC1B03000 Plug with gasket
			⑦	2 x 1C000xx Union end connection
			⑧	ACC0001 Adjustment key



FlowCon E-JUST.3 DN40-50 (1 1/2"-2") • Dynamic Balancing Valve

Valve housings		Insert	Accessories	
① AB40.I	Valve housing, DN40 (1 1/2") Brass	② E-JUST.3.G.B 50 mm E-JUST insert	③ ACC0084	Flushing cap
① AB50.I	Valve housing, DN50 (2") Brass		④ 2 x ACC00113	P/t plug with gasket
① AB40.DI	Valve housing, DN40 (1 1/2") Ductile iron		⑤ 2 x ACC1B03000	Plug with gasket
① AB50.DI	Valve housing, DN50 (2") Ductile iron		⑥ ACC0001	Adjustment key