



FlowCon E-JUST.1 DN15-25 (1/2"-1") • Partner Valve

Valve housings	Insert	Accessories
<ul style="list-style-type: none"> ① AB15.I Valve housing, DN15 (1/2") ① AB20.I Valve housing, DN20 (3/4") ① AB25.I.K Valve housing, DN25 (1") 	<ul style="list-style-type: none"> ② E-JUST.1.x.x 20 mm E-JUST insert 	<ul style="list-style-type: none"> ③ ACC0080 Flushing cap ④ ACC00110 Capillary tube ⑤ ACC00121 Union G 1/4" adaptor ⑥ ACC00103 T-piece ⑦ 2 x ACC00113 P/t plug with gasket ⑧ 2 x ACC1B03000 Plug with gasket ⑨ ACC0001 Adjustment key IPartner Insulation shell for ① (not shown)



FlowCon E-JUST.2 DN25-40 (1"-1 1/2") • Partner Valve

Valve housings		Insert		Accessories		
①	AB25.I	Valve housing, DN25 (1")	②	E-JUST.2.Y.G	40 mm E-JUST insert	
①	AB32.I	Valve housing, DN32 (1 1/4")				
				③	ACC0081	Flushing cap
				④	ACC00110	Capillary tube
				⑤	ACC00121	Union G 1/4" adaptor
				⑥	ACC00103	T-piece
				⑦	2 x ACC00113	P/t plug with gasket
				⑧	2 x ACC1B03000	Plug with gasket
				⑨	ACC0001	Adjustment key



FlowCon E-JUST.3 DN40-50 (1 1/2"-2") • Partner Valve

Valve housings		Insert		Accessories	
①	AB40.I Valve housing, DN40 (1 1/2")	②	E-JUST.3.G.B 50 mm E-JUST insert	③	ACC0084 Flushing cap
①	AB50.I Valve housing, DN50 (2")			④	ACC00110 Capillary tube
				⑤	ACC00121 Union G 1/4" adaptor
				⑥	ACC00103 T-piece
				⑦	2 x ACC00113 P/t plug with gasket
				⑧	2 x ACC1B03000 Plug with gasket
				⑨	ACC0001 Adjustment key